

DNF

1. Operation Summary

External interrupt signal(INT9) is generated by pressing SW1. The external interrupt signal through the digital noise filter turn on/off I

2. Setting

Push SW1 : Port E2

LED1 : Port J0

Connect J7 5pin (INT9) and J5 3pin(PE2) on the STK.

3. Basic Operation

- Every time you press SW1, it turn on/off LED.

LED.