

# T32A\_PPG

## 1. Operation Outline

When SW4 is operated, PPG output is started. Each time it is operated, stop PPG output and change the duty ratio.

## 2. Each Setting

SW : SW4 (PortA2)

Timer interrupt/ : INTT32A2AC/


Timer output T32A02OUTA (PU2)

## 3. Basic Operation

Function	Description
PPG output	Setting of the PPG output in the Timer function

SW	Function
S4 switch	PPG output and Duty change

Duty change



Changed by SW4 operation.

## 4. Note

Nothing.