

Application Note

TMPM3HQA UsersManual

Arm and Keil are registered trademarks of Arm Limited (or its subsidiaries) in the US and/or elsewhere.

All other company names, product names, and service names mentioned herein may be trademarks of their respective companies.

Table of Contents

Table of Contents.....	2
1. Preface	4
2. Technical Term	4
3. Reference Document	4
4. Operation Confirmation Condition	5
5. Used Channel and Port Assignment.....	5
5.1. User Interface	5
5.1.1. Push-Switch	5
5.1.2. Slide-Switch.....	5
5.1.3. LED.....	5
5.2. Communication	5
5.2.1. UART Communication.....	5
5.2.2. TSPI Communication	6
5.2.3. I2C Communication.....	6
5.2.4. EI2C Communication	6
5.3. Timer	6
5.4. ADC.....	7
5.5. A-ENC	7
5.6. DAC.....	7
5.7. Remote Controller.....	7
5.8. Digital LCD	7
6. System Setting.....	9
6.1.1. Power supply voltage	9
6.1.2. Clock setting	9
7. Communication Setting	10
7.1. UART Communication Setting.....	10
7.1.1. UART Setting	10
7.1.2. Log Control line feed code	10
7.1.3. Log Control error	10
7.1.4. Log Control and others.....	10
7.2. I2C Communication Setting	10
7.2.1. I2C Setting.....	10
7.2.2. Target Operating Specifications	10
7.3. SPI Communication Setting.....	11
7.1. BSP Slave Device Specifications	11
8. Flash Control range.....	12
8.1. Reference Manual.....	12
8.2. Code Flash Required specification control range.....	12
8.3. Code Flash User Information Required specification control range.....	12

8.4. Data Flash Required specification control range.....	12
9. DLCD	13
9.1. DLCD Control Device	13
10. Precautions for Use.....	14
11. Revision History	15
RESTRICTIONS ON PRODUCT USE	16

1. Preface

This application note describes a reference for the usage environment when running the sample program on TMPM3HQA.

If you select something other than TMPM3HQA on the MCU, a compile error may occur due to insufficient terminal or IP channel.

In that case, please modify the program and check the operation.

2. Technical Term

Term/Abbreviation	Definition
BSP	Board Support Package
UART	Universal Asynchronous Receiver Transmitter
LED	Light-emitting diode
TSPI	Toshiba Serial Peripheral Interface
EI2C	Enhanced Inter-Integrated Circuit

3. Reference Document

Document	Notes
TMPM3H Group (1) Data sheet	-
Reference manual	Refer to the reference manual of each IP to be used.
Application note	Refer to the application note of sample software to be used.

4. Operation Confirmation Condition

Item	Name	Version
Used Microcontroller	TMPM3HQFDAFG	-
Used Board	AdBun-M3HQA	-
Integrated Development Environment	IAR Embedded Workbench for ARM	9.60.0
Integrated Development Environment	Arm® Keil® MDK	5.40.00
Integrated Development Environment	SEGGER Embedded Studio	8.24
Sample Program	TXZp_TMPM3HQA_V200	V2.0.0

5. Used Channel and Port Assignment

5.1. User Interface

5.1.1. Push-Switch

Channel	Function	Port
BSP_PSW_1	Input	PV0
BSP_PSW_2	Input	PV1
BSP_PSW_3	Input	PV2
BSP_PSW_4	Input	PV3
BSP_PSW_5	Input	PC2

5.1.2. Slide-Switch

Channel	Function	Port
BSP_SSW_1	Input	PP6
BSP_SSW_2	Input	PP7
BSP_SSW_3	Input	-
BSP_SSW_4	Input	-

5.1.3. LED

Channel	Function	Port
BSP_LED_1	Output	PK4
BSP_LED_2	Output	PK5
BSP_LED_3	Output	PK6
BSP_LED_4	Output	PK7

5.2. Communication

5.2.1. UART Communication

Channel	Peripheral Channel	Function	Port
BSP_UART_1	ch0	BSP_UART1_TXD	PA1
		BSP_UART1_RXD	PA2
		BSP_UART1_CTS	-
		BSP_UART1_DTR	-
BSP_UART_2	-	BSP_UART2_TXD	-
		BSP_UART2_RXD	-
		BSP_UART2_CTS	-
		BSP_UART2_DTR	-

5.2.2. TSPI Communication

Channel	Peripheral Channel	Function	Port
BSP_TSPI_1	ch0	BSP_SPI1_TXD	PB3
		BSP_SPI1_RXD	PB4
		BSP_SPI1_SCK	PB2
		BSP_SPI1_CS	PB5
		BSP_SPI1_CSIN	PB5
BSP_TSPI_2	ch1	BSP_SPI2_TXD	-
		BSP_SPI2_RXD	-
		BSP_SPI2_SCK	-
		BSP_SPI2_CS	-
		BSP_SPI2_CSIN	-

5.2.3. I2C Communication

Channel	Peripheral Channel	Function	Port
BSP_I2C_1	ch1	BSP_I2C1_SCL	PA4
		BSP_I2C1_SDA	PA5
BSP_I2C_2	-	BSP_I2C2_SCL	-
		BSP_I2C2_SDA	-

5.2.4. EI2C Communication

Channel	Peripheral Channel	Function	Port
BSP_EI2C_1	ch1	BSP_EI2C1_SCL	PA4
		BSP_EI2C1_SDA	PA5
BSP_EI2C_2	-	BSP_EI2C2_SCL	-
		BSP_EI2C2_SDA	-

5.3. Timer

Channel	Peripheral Channel	Function	Port
BSP_T32A_1	BSP_T32A_TIMER_1	1ms Timer	-
BSP_T32A_2	BSP_T32A_PPG_1	ch3A: Pulse Output (T32A_PPG Sample)	PJ0
BSP_T32A_3	BSP_T32A_PPG_2	ch0A: Pulse Output (TRM Sample)	PA0
BSP_T32A_4	BSP_T32A_CAPT_1	ch2A: Pulse Output (TRM Sample)	PR1
BSP_T32A_5	BSP_T32A_TRM fs	-	-
BSP_T32A_6	BSP_T32A_CAPT_2	ch3B: Pulse Input (T32A_MEASURE Sample)	-

5.4. ADC

Channel	Peripheral Channel	Function	Port
BSP_ADC_1	BSP_THERMISTOR_1	Variable resistance voltage	PE0
BSP_ADC_2	BSP_VR_1	Variable resistance voltage	PD4
BSP_ADC_3	BSP_VR_2	Variable resistance voltage	PD5

5.5. A-ENC

Channel	Peripheral Channel	Function	Port
BSP_ENC_1	BSP_ENC1_A	Encoder input	PA0
	BSP_ENC1_B	Encoder input	PA1
	BSP_ENC1_Z	Encoder input	-
BSP_ENC_2	BSP_ENC2_A	Encoder input	-
	BSP_ENC2_B	Encoder input	-
	BSP_ENC2_Z	Encoder input	-

5.6. DAC

Channel	Peripheral Channel	Function	Port
BSP_ADC_1	-	-	PG0
BSP_ADC_2	-	-	PG1
BSP_ADC_3	-	-	-
BSP_ADC_4	-	-	-

5.7. Remote Controller

Channel	Peripheral Channel	Function	Port
BSP_RMC_1	-	-	PB1

5.8. Digital LCD

Channel	Peripheral Channel	Function	Port
BSP_DLCD_1	—	—	—
DCOM	BSP_DLCD_DCOM0	DCOM0	PC3
	BSP_DLCD_DCOM1	DCOM1	PC2
	BSP_DLCD_DCOM2	DCOM2	PC1
	BSP_DLCD_DCOM3	DCOM3	PC0
SEG	BSP_DLCD_SEG00	(BSP_PSW_4dual use)	PV3
	BSP_DLCD_SEG01	(BSP_PSW_3dual use)	PV2
	BSP_DLCD_SEG02	(BSP_PSW_2dual use)	PV1
	BSP_DLCD_SEG03	(BSP_PSW_1dual use)	PV0
	BSP_DLCD_SEG04	SEG04	PP7
	BSP_DLCD_SEG05	SEG05	PP6
	BSP_DLCD_SEG06	SEG06	PP5
	BSP_DLCD_SEG07	SEG07	PP4
	BSP_DLCD_SEG08	SEG08	PP3
	BSP_DLCD_SEG09	SEG09	PK7
	BSP_DLCD_SEG10	SEG10	PK6
	BSP_DLCD_SEG11	SEG11	PK5

	BSP_DLCD_SEG12	SEG12	PK4
	BSP_DLCD_SEG13	(MBEDIF_IO1 dual use)	PK3
	BSP_DLCD_SEG14	SEG14	PK2
	BSP_DLCD_SEG15	(MBEDIF_IO0 dual use)	PK1
	BSP_DLCD_SEG16	SEG16	PK0
	BSP_DLCD_SEG17	SEG17	PJ5
	BSP_DLCD_SEG18	SEG18	PJ4
	BSP_DLCD_SEG19	SEG19	PJ3
	BSP_DLCD_SEG20	(MBEDIF_RXD dual use)	PJ2
	BSP_DLCD_SEG21	(MBEDIF_TXD dual use)	PJ1
	BSP_DLCD_SEG22	SEG22	PJ0
	BSP_DLCD_SEG23	SEG23	PN0
	BSP_DLCD_SEG24	SEG24	PN1
	BSP_DLCD_SEG25	SEG25	PN2
	BSP_DLCD_SEG26	SEG26	PN3
	BSP_DLCD_SEG27	SEG27	PN4
	BSP_DLCD_SEG28	SEG28	PN5
	BSP_DLCD_SEG29	SEG29	PR7
	BSP_DLCD_SEG30	SEG30	PR6
	BSP_DLCD_SEG31	SEG31	PR5
	BSP_DLCD_SEG32	SEG13	PR4
	BSP_DLCD_SEG33	SEG15	PR3
	BSP_DLCD_SEG34	SEG20	PR2
	BSP_DLCD_SEG35	SEG21	PR1
	BSP_DLCD_SEG36	SEG00	PR0
	BSP_DLCD_SEG37	SEG01	PC6
	BSP_DLCD_SEG38	SEG02	PC5
	BSP_DLCD_SEG39	SEG03	PC4

6. System Setting

6.1.1. Power supply voltage

V	Notes
3.3	-

6.1.2. Clock setting

Clock	Function	MHz	Notes
fEHOSC	External oscillator	12	-
fIHOSC	Internal oscillator	10	-
fs	Low-speed oscillator	0.032768	-
fc	High-speed clock	120	-
fsys	High speed system clock	120	-
fsysh	High speed system clock	-	-
fsysm	Medium speed system clock	-	-
φT0	-	120	-
φT0h	High speed pre-scaler clock	-	-
φT0m	Medium speed pre-scaler clock	-	-

Note: It's basic setting. Settings change depending on the sample software.

7. Communication Setting

7.1. UART Communication Setting

7.1.1. UART Setting

Item	Setting Value	Notes
Baud Rate	115200(bps)	-
Data Length	8(bit)	-
Parity	None	-
Stop Bit	1(bit)	-
Flow Control	None	-

7.1.2. Log Control line feed code

Item	Setting Value	Notes
[line feed] (Send to Terminal emulator)	LF	-
[line feed] (Receive from Terminal emulator)	LF	-

7.1.3. Log Control error

Item	Setting Value	Notes
Error Log_Command	"Command Error!![line feed]"	When an unsupported command is entered
Error Log_Parameter	"Parameter Error!![line feed]"	Command parameter is not the expected value
Error Log_Input	"Input Error!![line feed]"	When an input request other than a command is not an expected value
Error Log_Erasing	"Erasing Error!![line feed]"	Used in Flash samples
Error Log_Writing	"Writing Error!![line feed]"	Used in Flash samples
Error Log_Reading	"Reading Error!![line feed]"	Used in Flash samples

7.1.4. Log Control and others

Item	Setting Value	Notes
MCU name	TMPM3HQFDA	-

7.2. I2C Communication Setting

7.2.1. I2C Setting

Item	Setting Value	Notes
I2C Clock (EI2C-A)	800KHz	In Concroller operation
I2C Clock (I2C-B)	400KHz	In Concroller operation
Data Length	8bit	-
Acknowledge	Available	-
Start/Stop Condition	Generated	-

7.2.2. Target Operating Specifications

Item	Setting Value	Notes
Target Address	0x60	Indicates 7bit that enters <7:1>
Sub Address Size	0x02	Sub Address is 2byte
Start Sub Address	0x0000	Indicates the leading Address of Sub Address
Data Size	0x10	Indicates the valid data size (byte) >>Sub Address range:0000-000F
Init Value	0x55	Initial value of Data.
Dummy Data	0xAA	This is returned when Read request is out of scope

7.3. SPI Communication Setting

Item	Setting Value	Notes
SPI Clock	10MHz	In Controller operation
Data Length	8bit	-
Parity	None	-
Data Transfer Direction	MSB	-

7.1. BSP Slave Device Specifications

Item	Specification	Notes
SPI Slave IC	ICM-20602	-

8. Flash Control range

8.1. Reference Manual

Reference manual	Notes
TXZ+ Family Reference Manual Flash Memory	FLASH512UD32-B

8.2. Code Flash Required specification control range

Flash Area	Start	Stop	Size	Notes
Code Flash All area	0x00000000	0x0007FFFF	512kbyte	
Code Flash Area 0	0x00000000	0x0007FFFF	512 kbyte	
Code Flash Block 0	0x00000000	0x00007FFF	32kbyte	User Boot
Code Flash Page 0	0x00000000	0x00000FFF	4 kbyte	
Code Flash Page 1	0x00001000	0x00001FFF	4 kbyte	
Code Flash Page 2	0x00002000	0x00002FFF	4 kbyte	
Code Flash Page 3	0x00003000	0x00003FFF	4 kbyte	
Code Flash Page 4	0x00004000	0x00004FFF	4 kbyte	
Code Flash Page 5	0x00005000	0x00005FFF	4 kbyte	
Code Flash Page 6	0x00006000	0x00006FFF	4 kbyte	
Code Flash Page 7	0x00007000	0x00007FFF	128byte	
Code Flash Page SIZE	0x00001000	—	4 kbyte	CODE areas Size
Code Flash Block 1	0x00008000	0x0000FFFF	32 kbyte	CODE areas A
Code Flash Block 2	0x00010000	0x00017FFF	32 kbyte	CODE areas B

8.3. Code Flash User Information Required specification control range

Code Area	Start	Stop	Notes	Notes
UserInformation All area	0x5E005000	0x5E005FFF	4 kbyte	

8.4. Data Flash Required specification control range

Code Area	Start	Stop	Notes	Notes
Data Flash All area	0x30000000	0x30007FFF	32 kbyte	
Data Flash Block 0	0x30000000	0x30000FFF	4 kbyte	
Data Flash Page 0	0x30000000	0x300000FF	256 byte	
Data Flash Page 1	0x30000100	0x300001FF	256 byte	
Data Flash Page SIZE	0x100	—	256 byte	

9. DLCD

9.1. DLCD Control Device

Item	Specification
DLCD_PANEL	S5038

10. Precautions for Use

Please confirm the operation sufficiently if use in an environment other than the operation check environment.

11. Revision History

Revision	Date	Description
1.0	2025-10-30	First release

RESTRICTIONS ON PRODUCT USE

Toshiba Corporation and its subsidiaries and affiliates are collectively referred to as "TOSHIBA".

Hardware, software and systems described in this document are collectively referred to as "Product".

- TOSHIBA reserves the right to make changes to the information in this document and related Product without notice.
- This document and any information herein may not be reproduced without prior written permission from TOSHIBA. Even with TOSHIBA's written permission, reproduction is permissible only if reproduction is without alteration/omission.
- Though TOSHIBA works continually to improve Product's quality and reliability, Product can malfunction or fail. Customers are responsible for complying with safety standards and for providing adequate designs and safeguards for their hardware, software and systems which minimize risk and avoid situations in which a malfunction or failure of Product could cause loss of human life, bodily injury or damage to property, including data loss or corruption. Before customers use the Product, create designs including the Product, or incorporate the Product into their own applications, customers must also refer to and comply with (a) the latest versions of all relevant TOSHIBA information, including without limitation, this document, the specifications, the data sheets and application notes for Product and the precautions and conditions set forth in the "TOSHIBA Semiconductor Reliability Handbook" and (b) the instructions for the application with which the Product will be used with or for. Customers are solely responsible for all aspects of their own product design or applications, including but not limited to (a) determining the appropriateness of the use of this Product in such design or applications; (b) evaluating and determining the applicability of any information contained in this document, or in charts, diagrams, programs, algorithms, sample application circuits, or any other referenced documents; and (c) validating all operating parameters for such designs and applications. **TOSHIBA ASSUMES NO LIABILITY FOR CUSTOMERS' PRODUCT DESIGN OR APPLICATIONS.**
- **PRODUCT IS NEITHER INTENDED NOR WARRANTED FOR USE IN EQUIPMENTS OR SYSTEMS THAT REQUIRE EXTRAORDINARILY HIGH LEVELS OF QUALITY AND/OR RELIABILITY, AND/OR A MALFUNCTION OR FAILURE OF WHICH MAY CAUSE LOSS OF HUMAN LIFE, BODILY INJURY, SERIOUS PROPERTY DAMAGE AND/OR SERIOUS PUBLIC IMPACT ("UNINTENDED USE").** Except for specific applications as expressly stated in this document, Unintended Use includes, without limitation, equipment used in nuclear facilities, equipment used in the aerospace industry, lifesaving and/or life supporting medical equipment, equipment used for automobiles, trains, ships and other transportation, traffic signaling equipment, equipment used to control combustions or explosions, safety devices, elevators and escalators, and devices related to power plant. **IF YOU USE PRODUCT FOR UNINTENDED USE, TOSHIBA ASSUMES NO LIABILITY FOR PRODUCT.** For details, please contact your TOSHIBA sales representative or contact us via our website.
- Product shall not be used for or incorporated into any products or systems whose manufacture, use, or sale is prohibited under any applicable laws or regulations.
- The information contained herein is presented only as guidance for Product use. No responsibility is assumed by TOSHIBA for any infringement of patents or any other intellectual property rights of third parties that may result from the use of Product. No license to any intellectual property right is granted by this document, whether express or implied, by estoppel or otherwise.
- **ABSENT A WRITTEN SIGNED AGREEMENT, EXCEPT AS PROVIDED IN THE RELEVANT TERMS AND CONDITIONS OF SALE FOR PRODUCT, AND TO THE MAXIMUM EXTENT ALLOWABLE BY LAW, TOSHIBA (1) ASSUMES NO LIABILITY WHATSOEVER, INCLUDING WITHOUT LIMITATION, INDIRECT, CONSEQUENTIAL, SPECIAL, OR INCIDENTAL DAMAGES OR LOSS, INCLUDING WITHOUT LIMITATION, LOSS OF PROFITS, LOSS OF OPPORTUNITIES, BUSINESS INTERRUPTION AND LOSS OF DATA, AND (2) DISCLAIMS ANY AND ALL EXPRESS OR IMPLIED WARRANTIES AND CONDITIONS RELATED TO SALE, USE OF PRODUCT, OR INFORMATION, INCLUDING WARRANTIES OR CONDITIONS OF MERCHANTABILITY, FITNESS FOR A PARTICULAR PURPOSE, ACCURACY OF INFORMATION, OR NONINFRINGEMENT.**
- Do not use or otherwise make available Product or related software or technology for any military purposes, including without limitation, for the design, development, use, stockpiling or manufacturing of nuclear, chemical, or biological weapons or missile technology products (mass destruction weapons). Product and related software and technology may be controlled under the applicable export laws and regulations including, without limitation, the Japanese Foreign Exchange and Foreign Trade Law and the U.S. Export Administration Regulations. Export and re-export of Product or related software or technology are strictly prohibited except in compliance with all applicable export laws and regulations.
- Please contact your TOSHIBA sales representative for details as to environmental matters such as the RoHS compatibility of Product. Please use Product in compliance with all applicable laws and regulations that regulate the inclusion or use of controlled substances, including without limitation, the EU RoHS Directive. **TOSHIBA ASSUMES NO LIABILITY FOR DAMAGES OR LOSSES OCCURRING AS A RESULT OF NONCOMPLIANCE WITH APPLICABLE LAWS AND REGULATIONS.**

Toshiba Electronic Devices & Storage Corporation

<https://toshiba.semicon-storage.com/>