

**M4G Group (1)**  
**Application Note**  
**Serial Peripheral Interface**  
**(TSPI-C)**

**Outlines**

This application note is a reference material for developing products using Serial peripheral interface (TSPI) function of M4G group (1). This document helps the user check operation of the product and develop its program.

Target sample program: TSPI\_ChToCh\_rx\_int


**Table of Contents**

Outlines.....	1
Table of Contents.....	2
1. Preface .....	3
2. Reference Document .....	4
3. Function to Use.....	4
4. Target Device.....	4
5. Operation Confirmation Condition .....	5
6. Evaluation Board Setting.....	6
7. Operation of Evaluation Board .....	6
8. Outline of TSPI Function .....	7
9. Sample Program .....	12
9.1. Initialization .....	12
9.2. Sample Program Main Operation.....	12
9.3. Output Example of Sample Program.....	13
9.3.1. Setting Example of Terminal Software.....	13
9.4. Operating Flow of Sample Program .....	14
10. Precaution.....	22
11. Revision History .....	22
RESTRICTIONS ON PRODUCT USE .....	23

## 1. Preface

This sample program should be used to check the operation of the Serial peripheral interface function. The “write” command transmits data. And the “read” command reads the reception data and outputs to the terminal software.

Structure diagram of Sample program



### 2. Reference Document

- Datasheet  
TMPM4G Group (1) datasheet Rev1.0 (Japanese edition)
- Reference manual  
Serial Communication (TSPI) Rev1.0 (Japanese edition)  
Asynchronous Serial Communication Circuit (UART-C) Rev3.0 (Japanese edition)
- Application note  
M4G Group (1) Application Note Startup (CMSIS System & Clock Configuration) Rev1.0
- Other reference document  
TMPM4G (1) Group Peripheral Driver User Manual (Doxygen)

### 3. Function to Use

IP	Channel	Port	Function/Operation mode
Serial Peripheral Interface	ch2	PA4 (TSPI2TXD) PA6 (TSPI2SCK) PA7 (TSPI2CS0)	SPI mode: Master
	ch4	PD0 (TSPI4CSIN) PD1 (TSPI4SCK) PD2 (TSPI4RXD)	SPI mode: Slave
Asynchronous Serial Communication Circuit	ch0	PE2 (UT0RXD) PE3 (UT0TXDA)	UART mode

### 4. Target Device

The target devices of this application note are as follows;

TMPM4G9F15FG	TMPM4G9F10FG	TMPM4G9FEFG	TMPM4G9FDFG
TMPM4G9F15XBG	TMPM4G9F10XBG	TMPM4G9FEXBG	TMPM4G9FDXBG
TMPM4G8F15FG	TMPM4G8F10FG	TMPM4G8FEFG	TMPM4G8FDFG
TMPM4G8F15XBG	TMPM4G8F10XBG	TMPM4G8FEXBG	TMPM4G8FDXBG
	TMPM4G7F10FG	TMPM4G7FEFG	TMPM4G7FDFG
	TMPM4G6F10FG	TMPM4G6FEFG	TMPM4G6FDFG

\* This sample program operates on the evaluation board of TMPM4G9F15FG.


If other function than the TMPM4G9F15 one is checked, it is necessary that CMSIS Core related files (C startup file and I/O header file) should be changed properly.

The BSP related file is dedicated to the evaluation board (TMPM4G9F15). If other function than the TMPM4G9F15 one is checked, the BSP related file should be changed properly.

### 5. Operation Confirmation Condition

Used microcontroller	TMPM4G9F15FG
Used board	TMPM4G9F15FG Evaluation Board by Sensyst
Unified development environment	IAR Embedded Workbench for ARM 8.11.2.13606
Unified development environment	µVision MDK Version 5.24.2.0
Terminal software	Tera Term V4.96
Sample program	V1000

Evaluation board (TMPM4G9F15FG Evaluation Board) Top view




## 6. Evaluation Board Setting

The following pin connections should be done on the evaluation board.

CN5		
Board function	Through-hole No.	Through-hole No.
USB UART conversion	1: USB_UT_RX	2: PE2
USB UART conversion	3: USB_UT_TX	4: PE3

CN18		
Board function	Through-hole No.	Through-hole No.
SPI communication (Inter-channel)	7: PD2	35: PA4
SPI communication (Inter-channel)	9: PD1	40: PA6
SPI communication (Inter-channel)	11: PD0	39: PA7



## 7. Operation of Evaluation Board

PC and the USB\_UART are connected for communication with the terminal software.

The sample program should be started up.

The sample program waits for data input to the terminal software.

The “write” command should be input to the terminal software. Then the “read” command should be input.

The data received by the “write” command is read and the character string “TOSHIBA” is output to the terminal software.

## 8. Outline of TSPI Function

TSPI (serial peripheral interface) has four operation mode as SPI/SIO mode, and the clock master/ clock slave mode. One channel/unit which is built-in TSPIxTXD, TSPIxRXD, TSPIxSCK, TSPIxCS0, TSPIxCS1, TSPIxCS2, TSPIxCS3, and TSPIxCSIN can be transmit and receive circuit. Functions are as below.

Table 8.1 Functional outline (SPI mode, master)

Function classification		Function	A Functional Description or the range	
SPI mode (Master)	Transmission Speed Control	Prescaler dividing selection	The clock inputted from the prescaler can be divided 1/1, 1/2, 1/4...up to 1/512.	
		Baud rate generator	The input clock to baud rate generator. dividing $1/N \times 1/2$ (N= 1 to 16)	
	Data Format	Data length	The data length can be setup in a 1-bit unit. 8 to 32bits (with no parity) 7 to 31bits (with parity)	
		Parity	Selection of with parity/without parity is possible. Selection of even parity/odd parity is possible.	
		The direction of data transfer	Selection of the LSB first/ MSB first is possible.	
	Transmission and Reception Control	FIFO number of section	Transmission: 8 steps (16bits), 4 steps (32bits) Reception: 8 steps (16bits), 4 steps (32bits)	
		Communication Operation mode	Full duplexes (transmission and reception), transmission, reception	
		Transfer mode	Single transfer (one burst transfer) Burst transfer (2 to 255 times transfer) Continuously transfer (No limit of transfer times specification)	
		Data sampling timing	Data is sampled with 1st edge. Data is sampled with 2nd edge.	
		CS control	Selection of TSPIxCS0/1/2/3 is possible. Polarity: Selection of positive logic/ negative logic is possible.	
	Ganged Control	Interruption	Transmit interrupt (Transmit completion interrupt, Transmit FIFO interrupt) Receive interrupt (Receive completion interrupt, Receive FIFO interrupt) Error Interrupt (Vertical parity error interrupt, Trigger error interrupt)	
			Various status detection	TSPI modify status, Transmit shift operation, Transmit completion, Transmit FIFO fill level/ empty detection, Receive operation, Receive completion, Receive FIFO fill level /full detection
			DMA request	Transmit: Single DMA request, burst DMA request Receive: Single DMA transfer, burst DMA request
		Trigger communication control	Starting communication by trigger. Refer to the "Product Information" on a reference manual for a trigger source.	
	Special Control	Output level of TSPIxTXD during an idle term	High, Low, a last bit data hold, Hi-z	
		Polarity of TSPIxSCK during an idle term	It is Low to during idle term. It is High to during idle term.	
		Interval time between frames at the time of burst transfer.	0 x TSPIxSCK cycle to 15 x TSPIxSCK cycles	
		Idle time at the time of continuously transfer.	Period of changing TSPIxCS0/1/2/3 pin to asserted, deasserted, asserted. 1 x TSPIxSCK cycle to 15 x TSPIxSCK cycles	
		TSPIxSCK delay of deassert	Time of delay between from TSPIxCS0/1/2/3 is asserted to TSPIxSCK is started. 1 x TSPIxSCK cycle to 16 x TSPIxSCK cycles	
		TSPIxCS0/1/2/3 deassertion delay	Time until TSPIxCS0/1/2/3 pin is deasserted from last data 1 x TSPIxSCK cycle to 16 x TSPIxSCK cycle	
		Software reset	Reset by software is possible.	

Table 8.2 Outline of function (SPI mode and Slave)

Function classification		Function	A Functional Description or the range
SPI mode (Slave)	Data Format	Data length	The data length can be setup in a 1-bit unit. 8 to 32bits (with no parity) 7 to 31bits (with parity)
		Parity	Selection of with parity/without parity is possible. Selection of even parity/odd parity is possible.
		The direction of data transfer	Selection of the LSB first/ MSB first is possible.
	Transmission and Reception Control	FIFO number of section	Transmission: 8 steps (16bits), 4 steps (32bits) Reception: 8 steps (16bits), 4 steps (32bits)
		Communication Operation mode	Full duplexes (transmission and reception), transmission, reception
		Transfer mode	Single transfer (one burst transfer) Burst transfer (2 to 255 times transfer) Continuously transfer (No limit of transfer times specification)
		Data sampling timing	Data is sampled with 2nd edge.
		CS control	TSPIxCSIN Polarity: Selection of positive logic/ negative logic is possible.
	Ganged Control	Interruption	Transmit interrupt (Transmit completion interrupt, Transmit FIFO interrupt) Receive interrupt (Receive completion interrupt, Receive FIFO interrupt) Error Interrupt (Vertical parity error interrupt, Overrun interrupt, Underrun interrupt)
		Various status detection	TSPI modify status, Transmit shift operation, Transmit completion, Transmit FIFO fill level/ empty detection, Receive operation, Receive completion, Receive FIFO fill level /full detection
		DMA request	Transmit: Single DMA request, burst DMA request Receive: Single DMA transfer, burst DMA request
	Special Control	Output level of TSPIxTXD during an idle term	High, Low, a last bit data hold, Hi-z
		Output level of TSPIxTXD when underrun error occurred	High, Low
		Software reset	Reset by software is possible.

Table 8.3 Outline of function (SIO mode and Master)

Function classification		Function	A Functional Description or the range	
SIO mode (Master)	Transmission speed Control	Prescaler dividing selection	The clock inputted from the prescaler can be divided 1/1, 1/2, 1/4..up to 1/512.	
		Baud rate generator	The input clock to baud rate generator. dividing 1/N x 1/2 (N= 1 to 16)	
	Data Format	Data length	The data length can be setup in a 1-bit unit. 8 to 32bits (with no parity) 7 to 31bits (with parity)	
		Parity	Selection of with parity/without parity is possible. Selection of even parity/odd parity is possible.	
		The direction of data transfer	Selection of the LSB first/ MSB first is possible.	
	Transmission and Reception Control	FIFO number of section	Transmission: 8 steps (16bits), 4 steps (32bits) Reception: 8 steps (16bits), 4 steps (32bits)	
		Communication Operation mode	Full duplexes (transmission and reception), transmission, reception	
		Transfer mode	Single transfer (one burst transfer) Burst transfer (2 to 255 times transfer) Continuously transfer (No limit of transfer times specification)	
		Data sampling timing	Data is sampled with 1st edge. Data is sampled with 2nd edge.	
	Ganged Control	Interruption		Transmit interrupt (Transmit completion interrupt, Transmit FIFO interrupt) Receive interrupt (Receive completion interrupt, Receive FIFO interrupt) Error Interrupt (Vertical parity error interrupt, Trigger error interrupt)
			Various status detection	TSPIx modify status, Transmit shift operation, Transmit completion, Transmit FIFO fill level/ empty detection, Receive operation, Receive completion, Receive FIFO fill level /full detection
		DMA request	Transmit: Single DMA request, burst DMA request Receive: Single DMA transfer, burst DMA request	
		Trigger communication control	Starting communication by trigger. Refer to the "Product Information" on a reference manual for a trigger source.	
	Special Control	Output level of TSPIxTXD during an idle term	High, Low, a last bit data hold, Hi-z	
		Polarity of TSPIxSCK during an idle term	It is Low to during idle term. It is High to during idle term.	
		Interval time between frames at the time of burst transfer.	0 x TSPIxSCK cycle to 15 x TSPIxSCK cycles	
		Idle time at the time of continuously transfer.	Period of changing TSPIxCS0/1/2/3 pin to asserted, deasserted, asserted.. 1 x TSPIxSCK cycle to 15 x TSPIxSCK cycles	
		Software reset	Reset by software is possible.	

Table 8.4 Outline of function (SIO mode and Slave)

Function classification		Function	A Functional Description or the range
SIO mode (Slave)	Data Format	Data length	The data length can be setup in a 1-bit unit. 8 to 32bits (with no parity) 7 to 31bits (with parity)
		Parity	Selection of with parity/without parity is possible. Selection of even parity/odd parity is possible.
		The direction of data transfer	Selection of the LSB first/ MSB first is possible.
	Transmission and Reception Control	FIFO number of section	Transmission: 8 steps (16bits), 4 steps (32bits) Reception: 8 steps (16bits), 4 steps (32bits)
		Communication Operation mode	Full duplexes (transmission and reception), transmission, reception
		Transfer mode	Single transfer (one burst transfer) Burst transfer (2 to 255 times transfer) Continuously transfer (No limit of transfer times specification)
		Data sampling timing	Data is sampled with 2nd edge.
	Ganged Control	Interruption	Transmit interrupt (Transmit completion interrupt, Transmit FIFO interrupt) Receive interrupt (Receive completion interrupt, Receive FIFO interrupt) Error Interrupt (Vertical parity error interrupt, Overrun interrupt, Underrun interrupt)
		Various status detection	TSPI modify status, Transmit shift operation, Transmit completion, Transmit FIFO fill level/ empty detection, Receive operation, Receive completion, Receive FIFO fill level /full detection
		DMA request	Transmit: Single DMA request, burst DMA request Receive: Single DMA transfer, burst DMA request
	Special Control	Final bit hold time of a TSPIxTXD pin	2/fsys to 128/fsys
		Output level of TSPIxTXD during an idle term	High, Low, a last bit data hold, Hi-z
		Software reset	Reset by software is possible.

## 9. Sample Program

The TSPI is used to communicate data. The “write” command transmits data. And the “read” command reads the reception data and outputs to the terminal software.

The UART communication is used to transfer the commands and data to the terminal software.

### 9.1. Initialization

The following initialization is done after power is supplied.

The initialization of each clock setting and the setting of the watchdog timer are done.

### 9.2. Sample Program Main Operation

The BSP (Board Support Package) is initialized.

As initialization of the application software, the initialization of the transmission and reception for the UART and the TSPI is done.

The sample program waits for the “write” or “read” command which is input with the terminal software.

The execution of each command is as follows;

- write  
After the TSPI transmission and reception interrupts are enabled, the preset character string “TOSHIBA” is transmitted. After the data is transmitted, the TSPI ch4 reception interrupt is generated, and the data is received.
- read  
The reception data is read and output to the terminal software.

### 9.3. Output Example of Sample Program


When the sample program executes, the command input and its result are displayed as shown in the following figure.

```
command > write
command > read
read data > TOSHIBA
command > 123456

Command Error !!
command >
```


#### 9.3.1. Setting Example of Terminal Software


The operation of the terminal software (Tera Term) has been checked with the following settings.






### 9.4. Operating Flow of Sample Program


The basic operating flows of the sample program are shown in the following;




















**10. Precaution**

When using the sample program with CPU other than TPM4G9F15, please check operation sufficiently.

**11. Revision History**

Rev	Date	Page	Description
1.0	2018-12-14	-	First release

### RESTRICTIONS ON PRODUCT USE

Toshiba Corporation and its subsidiaries and affiliates are collectively referred to as "TOSHIBA". Hardware, software and systems described in this document are collectively referred to as "Product".

- TOSHIBA reserves the right to make changes to the information in this document and related Product without notice.
- This document and any information herein may not be reproduced without prior written permission from TOSHIBA. Even with TOSHIBA's written permission, reproduction is permissible only if reproduction is without alteration/omission.
- Though TOSHIBA works continually to improve Product's quality and reliability, Product can malfunction or fail. Customers are responsible for complying with safety standards and for providing adequate designs and safeguards for their hardware, software and systems which minimize risk and avoid situations in which a malfunction or failure of Product could cause loss of human life, bodily injury or damage to property, including data loss or corruption. Before customers use the Product, create designs including the Product, or incorporate the Product into their own applications, customers must also refer to and comply with (a) the latest versions of all relevant TOSHIBA information, including without limitation, this document, the specifications, the data sheets and application notes for Product and the precautions and conditions set forth in the "TOSHIBA Semiconductor Reliability Handbook" and (b) the instructions for the application with which the Product will be used with or for. Customers are solely responsible for all aspects of their own product design or applications, including but not limited to (a) determining the appropriateness of the use of this Product in such design or applications; (b) evaluating and determining the applicability of any information contained in this document, or in charts, diagrams, programs, algorithms, sample application circuits, or any other referenced documents; and (c) validating all operating parameters for such designs and applications. **TOSHIBA ASSUMES NO LIABILITY FOR CUSTOMERS' PRODUCT DESIGN OR APPLICATIONS.**
- **PRODUCT IS NEITHER INTENDED NOR WARRANTED FOR USE IN EQUIPMENTS OR SYSTEMS THAT REQUIRE EXTRAORDINARILY HIGH LEVELS OF QUALITY AND/OR RELIABILITY, AND/OR A MALFUNCTION OR FAILURE OF WHICH MAY CAUSE LOSS OF HUMAN LIFE, BODILY INJURY, SERIOUS PROPERTY DAMAGE AND/OR SERIOUS PUBLIC IMPACT ("UNINTENDED USE").** Except for specific applications as expressly stated in this document, Unintended Use includes, without limitation, equipment used in nuclear facilities, equipment used in the aerospace industry, lifesaving and/or life supporting medical equipment, equipment used for automobiles, trains, ships and other transportation, traffic signaling equipment, equipment used to control combustions or explosions, safety devices, elevators and escalators, and devices related to power plant. **IF YOU USE PRODUCT FOR UNINTENDED USE, TOSHIBA ASSUMES NO LIABILITY FOR PRODUCT.** For details, please contact your TOSHIBA sales representative or contact us via our website.
- Product shall not be used for or incorporated into any products or systems whose manufacture, use, or sale is prohibited under any applicable laws or regulations.
- The information contained herein is presented only as guidance for Product use. No responsibility is assumed by TOSHIBA for any infringement of patents or any other intellectual property rights of third parties that may result from the use of Product. No license to any intellectual property right is granted by this document, whether express or implied, by estoppel or otherwise.
- **ABSENT A WRITTEN SIGNED AGREEMENT, EXCEPT AS PROVIDED IN THE RELEVANT TERMS AND CONDITIONS OF SALE FOR PRODUCT, AND TO THE MAXIMUM EXTENT ALLOWABLE BY LAW, TOSHIBA (1) ASSUMES NO LIABILITY WHATSOEVER, INCLUDING WITHOUT LIMITATION, INDIRECT, CONSEQUENTIAL, SPECIAL, OR INCIDENTAL DAMAGES OR LOSS, INCLUDING WITHOUT LIMITATION, LOSS OF PROFITS, LOSS OF OPPORTUNITIES, BUSINESS INTERRUPTION AND LOSS OF DATA, AND (2) DISCLAIMS ANY AND ALL EXPRESS OR IMPLIED WARRANTIES AND CONDITIONS RELATED TO SALE, USE OF PRODUCT, OR INFORMATION, INCLUDING WARRANTIES OR CONDITIONS OF MERCHANTABILITY, FITNESS FOR A PARTICULAR PURPOSE, ACCURACY OF INFORMATION, OR NONINFRINGEMENT.**
- Do not use or otherwise make available Product or related software or technology for any military purposes, including without limitation, for the design, development, use, stockpiling or manufacturing of nuclear, chemical, or biological weapons or missile technology products (mass destruction weapons). Product and related software and technology may be controlled under the applicable export laws and regulations including, without limitation, the Japanese Foreign Exchange and Foreign Trade Law and the U.S. Export Administration Regulations. Export and re-export of Product or related software or technology are strictly prohibited except in compliance with all applicable export laws and regulations.
- Please contact your TOSHIBA sales representative for details as to environmental matters such as the RoHS compatibility of Product. Please use Product in compliance with all applicable laws and regulations that regulate the inclusion or use of controlled substances, including without limitation, the EU RoHS Directive. **TOSHIBA ASSUMES NO LIABILITY FOR DAMAGES OR LOSSES OCCURRING AS A RESULT OF NONCOMPLIANCE WITH APPLICABLE LAWS AND REGULATIONS.**