

# **Application Note**

# DMAC\_UART

Arm and Keil are registered trademarks of Arm Limited (or its subsidiaries) in the US and/or elsewhere.

All other company names, product names, and service names mentioned herein may be trademarks of their respective companies.

# **Table of Contents**

Table of Contents	.2
1. Preface	.3
2. Technical Term	.3
3. Reference Document	.3
4. Target Sample Program	.4
5. Configuration Diagram	.4
6. Sample Program : DMAC_UART	.5
6.1. Outlines of Operation	. 5
6.1.1. Basic operation	5
6.1.2. Processing when an error occurs	5
6.2. Function to Use	. 5
6.3. Interrupt to Use	. 5
6.4. Configuration	. 5
6.5. Example of Terminal Emulator Output	. 6
6.5.1. Normal Operation	6
6.5.2. Case of Error Occurrence	6
7. DMAC Driver	.6
8. UART Driver	.6
9. Revision History	.7
RESTRICTIONS ON PRODUCT USE	.8

### 1. Preface

This application note describes sample software for the transfers data by UART communication using the DMAC function.

This document helps the user check operation of a product under development and develop its program.

## 2. Technical Term

Term/Abbreviation	Definition
DMAC	Direct Memory Access Controller
BSP	Board Support Package
CG	Clock control and Operation Mode
Timer	T32A : 32-bit Timer Event Counter
UART	Universal Asynchronous Receiver Transmitter


### 3. Reference Document

Document	Notes
Data sheet	Refer to the data sheet of MCU to be used.
Reference manual	Refer to the reference manual of each IP to be used.
Application note MCU User Guide	Refer to the MCU user guide to be used.

# 4. Target Sample Program

Sample Program	Outline
DAC_UART	Sample program of DMAC function

# 5. Configuration Diagram



### 6. Sample Program : DMAC\_UART

This is sample software that performs memory to peripheral / peripheral to memory transfer using the DMAC function and UART communication.

#### 6.1. Outlines of Operation

Echo back the data input from the terminal emulator. DMAC is used for data input / output with the terminal emulator.

#### 6.1.1. Basic operation

Output Log\_1 to BSP\_UART\_1 (terminal emulator) and wait for data input of BSP\_UART\_1. Input of BSP\_UART\_1 and reception of [Line feed] are judged as input completion. After outputting Log\_2 to BSP\_UART\_1, the input data is echoed back.

#### 6.1.2. Processing when an error occurs

If the BSP\_UART\_1 input exceeds the Max data size, error Log\_1 is output to BSP\_UART\_1.

#### 6.2. Function to Use

The functions to use are as follows.

For the Port assignment of each channel, refer to the MCU user guide.

IP	Channel	Objective
UART	BSP_UART_1	For terminal emulator communication (Outputs log)

#### 6.3. Interrupt to Use

Interrupt	Outlines
INTDMAATC	DMAC Unit A Transfer end interrupt
INTDMAAERR	DMAC Unit A Transfer error interrupt
INTT32A00A	T32A Timer A
INTISZAUDA	Timer counter increment every 1ms for display update

#### 6.4. Configuration

Configuration	Current Value	Description
Max Data size	32	32 characters
DMAC Transfer (for reception)	1	Forwarding address increment (byte)
	1	Forwarding data size (byte)
	No increment	Increment of forwarding address (byte)
	1	Transfer source data size (byte)
	1	Execution unit of arbitration
	Burst transfer	Single / burst transfer
	Unit normal transfer	Transfer mode
DMAC Transfer (for transmission)	No increment	Forwarding address increment (byte)
	1	Forwarding data size (byte)
	1	Increment of forwarding address (byte)
	1	Transfer source data size (byte)
	1	Execution unit of arbitration
	Burst transfer	Single / burst transfer
	Unit normal transfer	Transfer mode
Output Log_1	"Input = "	Input is confirmed by "[line feed]"
Output Log_2	"Echo = xx[line feed]"	xx : Data from terminal software
Error Log_1	Error Log_ input value	-

# 6.5. Example of Terminal Emulator Output

## 6.5.1. Normal Operation

Input = 12345 Echo = 12345

Input = 12345678901234567890123456789012 Echo = 12345678901234567890123456789012

### 6.5.2. Case of Error Occurrence

Input = 123456789012345678901234567890123 Input Error !!

### 7. DMAC Driver

The DMAC is controlled by using the following interface. For an example of use, refer to the source code.

Driver	Control Outlines
dma_init	DMAC Initialize the object
dma_deinit	DMAC Release the object
dma_irq_handler	IRQ Handler
dma_error_irq_handler	Error IRQ Handler
dma_get_error	Get error
dma_clear_error	Clear error
dma_ch_init	DMAC Initialization of channel object
dma_ch_deinit	DMAC Release channel object
dma_startIt	DMAC Mode start
dma_stoplt	DMAC Mode stop
dma_sw_request	DMAC Request Self Trigger
dma_normal_startIt	DMAC Start normal mode
dma_normal_stopIt	DMAC Stop in normal mode
dma_normal_cnt_startIt	DMAC Continuation Start mode
dma_normal_cnt_stopIt	DMAC Continuation Stop mode
dma_cnt_chain_startIt	DMAC Continuation Chain Start mode
dma_cnt_chain_stopIt	DMAC Continuation Chain Stop mode
dma_chain_startIt	DMAC Chain Start mode
dma_chain_stopIt	DMAC Chain Stop mode

# 8. UART Driver

See the application note "UART" for details.

# 9. Revision History

Revision	Date	Description
1.0	2023-06-28	First release

### **RESTRICTIONS ON PRODUCT USE**

Toshiba Corporation and its subsidiaries and affiliates are collectively referred to as "TOSHIBA". Hardware, software and systems described in this document are collectively referred to as "Product".

- TOSHIBA reserves the right to make changes to the information in this document and related Product without notice.
- This document and any information herein may not be reproduced without prior written permission from TOSHIBA. Even with TOSHIBA's written permission, reproduction is permissible only if reproduction is without alteration/omission.
- Though TOSHIBA works continually to improve Product's quality and reliability, Product can malfunction or fail. Customers are responsible for complying with safety standards and for providing adequate designs and safeguards for their hardware, software and systems which minimize risk and avoid situations in which a malfunction or failure of Product could cause loss of human life, bodily injury or damage to property, including data loss or corruption. Before customers use the Product, create designs including the Product, or incorporate the Product into their own applications, customers must also refer to and comply with (a) the latest versions of all relevant TOSHIBA information, including without limitation, this document, the specifications, the data sheets and application notes for Product and the precautions and conditions set forth in the "TOSHIBA Semiconductor Reliability Handbook" and (b) the instructions for the application with which the Product will be used with or for. Customers are solely responsible for all aspects of their own product design or applications, including but not limited to (a) determining the appropriateness of the use of this Product in such design or applications; (b) evaluating and determining the applicability of any information contained in this document, or in charts, diagrams, programs, algorithms, sample application circuits, or any other referenced documents; and (c) validating all operating parameters for such designs and applications. TOSHIBA ASSUMES NO LIABILITY FOR CUSTOMERS' PRODUCT DESIGN OR APPLICATIONS.
- PRODUCT IS NEITHER INTENDED NOR WARRANTED FOR USE IN EQUIPMENTS OR SYSTEMS THAT REQUIRE EXTRAORDINARILY HIGH LEVELS OF QUALITY AND/OR RELIABILITY, AND/OR A MALFUNCTION OR FAILURE OF WHICH MAY CAUSE LOSS OF HUMAN LIFE, BODILY INJURY, SERIOUS PROPERTY DAMAGE AND/OR SERIOUS PUBLIC IMPACT ("UNINTENDED USE"). Except for specific applications as expressly stated in this document, Unintended Use includes, without limitation, equipment used in nuclear facilities, equipment used in the aerospace industry, lifesaving and/or life supporting medical equipment, equipment used for automobiles, trains, ships and other transportation, traffic signaling equipment, equipment used to control combustions or explosions, safety devices, elevators and escalators, and devices related to power plant. IF YOU USE PRODUCT FOR UNINTENDED USE, TOSHIBA ASSUMES NO LIABILITY FOR PRODUCT. For details, please contact your TOSHIBA sales representative or contact us via our website.
- Do not disassemble, analyze, reverse-engineer, alter, modify, translate or copy Product, whether in whole or in part.
- Product shall not be used for or incorporated into any products or systems whose manufacture, use, or sale is prohibited under any applicable laws or regulations.
- The information contained herein is presented only as guidance for Product use. No responsibility is assumed by TOSHIBA for any infringement of patents or any other intellectual property rights of third parties that may result from the use of Product. No license to any intellectual property right is granted by this document, whether express or implied, by estoppel or otherwise.
- ABSENT A WRITTEN SIGNED AGREEMENT, EXCEPT AS PROVIDED IN THE RELEVANT TERMS AND CONDITIONS OF SALE FOR PRODUCT, AND TO THE MAXIMUM EXTENT ALLOWABLE BY LAW, TOSHIBA (1) ASSUMES NO LIABILITY WHATSOEVER, INCLUDING WITHOUT LIMITATION, INDIRECT, CONSEQUENTIAL, SPECIAL, OR INCIDENTAL DAMAGES OR LOSS, INCLUDING WITHOUT LIMITATION, LOSS OF PROFITS, LOSS OF OPPORTUNITIES, BUSINESS INTERRUPTION AND LOSS OF DATA, AND (2) DISCLAIMS ANY AND ALL EXPRESS OR IMPLIED WARRANTIES AND CONDITIONS RELATED TO SALE, USE OF PRODUCT, OR INFORMATION, INCLUDING WARRANTIES OR CONDITIONS OF MERCHANTABILITY, FITNESS FOR A PARTICULAR PURPOSE, ACCURACY OF INFORMATION, OR NONINFRINGEMENT.
- Do not use or otherwise make available Product or related software or technology for any military purposes, including without limitation, for the design, development, use, stockpiling or manufacturing of nuclear, chemical, or biological weapons or missile technology products (mass destruction weapons). Product and related software and technology may be controlled under the applicable export laws and regulations including, without limitation, the Japanese Foreign Exchange and Foreign Trade Law and the U.S. Export Administration Regulations. Export and re-export of Product or related software or technology are strictly prohibited except in compliance with all applicable export laws and regulations.
- Please contact your TOSHIBA sales representative for details as to environmental matters such as the RoHS compatibility of Product. Please
  use Product in compliance with all applicable laws and regulations that regulate the inclusion or use of controlled substances, including
  without limitation, the EU RoHS Directive. TOSHIBA ASSUMES NO LIABILITY FOR DAMAGES OR LOSSES OCCURRING AS A RESULT
  OF NONCOMPLIANCE WITH APPLICABLE LAWS AND REGULATIONS.

# **Toshiba Electronic Devices & Storage Corporation**

https://toshiba.semicon-storage.com/