

CPU Program Counter/Register

Self-diagnosis Program

Application Note

Outlines

This application note describes the self-diagnosis program for the CPU.

The self-diagnosis program in this document is the library which checks the CPU program counters and registers.

This library supports the sample program with the peripheral driver of TXZ series enclosed, and should be used after it is overwritten to the sample program.

Table of Contents

Outlines.....	1
Table of Contents.....	2
1. Preface	4
2. Outline of Self-diagnosis Test Library.....	5
2.1. Self-diagnosis Sample Project.....	5
3. Details of Self-diagnosis Test Library	6
3.1. CPU Register Test.....	6
3.2. CPU Program Counter Test.....	7
4. List of Used Drivers	8
5. Reference Document	9
6. Revision History	10
RESTRICTIONS ON PRODUCT USE	11

Arm, Cortex and Keil are registered trademarks of Arm Limited (or its subsidiaries) in the US and/or elsewhere.

All other company names, product, and service names mentioned herein may be trademarks or registered trademarks of respective companies.

1. Preface

This application note describes the self-diagnosis program which uses the CPU program counter test and register test.

This library code should be used after it is added (overwritten) to the published sample program.

The explanation of this document uses the TPM4K Group (1).

When the program is applied to a product, some appropriate modification may be necessary depending on the specifications of the product.

This sample program has been developed and evaluated under the conditions in the operation confirmation environment in “Self-diagnosis Program Application Note – Basic Setting”, and by using the TPM4K4A 1.0.0 sample program and the reference manual released in February in 2019.

2. Outline of Self-diagnosis Test Library

This self-diagnosis test library has been checked on the evaluation board.

The following self-test function is supported.

Name	Description
CPU register test	All writable and readable registers are tested. The checker patterns of 0x55555555 and 0xAAAAAAAA are written to the registers and read from the registers. It is checked whether the read data is correct or not.
CPU program counter test	After a jump instruction is executed, it is checked that the value in the PC is the same as the expected value at describing the program (at the build). 10 jump destination addresses are prepared. When all jumps are executed correctly, the program step returns to the source address of the call.

2.1. Self-diagnosis Sample Project

In the “Project\Examples\Safety” folder, the following sample project for the self-diagnosis library is placed.

Project name	Operation	Utilized self-diagnosis library function
CPU_Sample	The CPU register test and the CPU program counter test are executed. The result is shown with the LED lighting.	safety_CPU_Register() safety_CPU_ProgramCounter()

3. Details of Self-diagnosis Test Library

This section describes the details of the self-diagnosis test library function.
 This sample program is a self-diagnosis program for the CPU program counters and registers.
 The following setting is an example when a product in the TPM4K group (1) is used.

The source code (.c file) of the self-diagnosis library is in the "Libraries\Safety\src" folder, and the header file (.h file) is in the "Libraries\Safety\inc" folder.

3.1. CPU Register Test

"Stuck at" error check(Note1) for the CPU registers is done to the following CPU registers.

- R0 to R12
- R13 (Main SP and Process SP) (Note2)
- R14 (LR)
- CPSR (only upper 5 bits)

The CPU register test checks the registers in turn.

When an error of a register is detected, the test is suspended and the error result is returned. The bit mask value which identifies the register is also returned.

The library function is supposed to be called in the privilege status (not the user status).

This library function should be called while the interrupts are disabled.

The registers which are set to non-destructive ones at the call in C-language are protected before and after the test execution.

The "safety_CPU_Register" function does not use any interrupts.

Source file: safety_cpu_reg.c

Header file: safety_cpu_reg.h

Used library: txz_gpio.c/h

Function name	
bool safety_CPU_Register(uint32_t *result_word)	
Input parameter	
None.	-
Output parameter	
uint32_t *result_word	Memory buffers which store the results. bit0 to bit12: R0 to R12 test failure bit13: Main SP test failure bit14: Process SP test failure bit15: LR test failure bit16: CPSR test failure
Return value	
bool	Test result (true: success, false: failure)

* If the return value cannot be confirmed for several seconds, it is supposed the test is not executed correctly.
 The process for the test failure should be done.
 When, however, the terminal I/O output display is used, it takes several seconds to complete the display.
 The judgment of the test failure should be done by checking the display.

Note1: "Stuck at" check detects the abnormal error that a bit value is fixed to 0 or 1.

Note2: The least 2 bits of the SP register are fixed to 0. These bits are not tested.

3.2. CPU Program Counter Test

“Stuck at” error is checked for the CPU program counter.
Multiple jump instructions are executed in this function instead that the program counter is set to a value.
If the test fails, the program has some error. The error in the program cannot be recovered automatically.

On the other hand, when the execution completes, the test is successful.

This library function should be called while the interrupts are disabled. The registers which are set to non-destructive ones at the call in C-language are protected before and after the test execution.

The “safety_CPU_ProgramCounter” function does not use any interrupts.

Source file: safety_cpu_pc.c
Header file: safety_cpu_pc.h
Used library: txz_gpio.c/.h

Function name	
bool safety_CPU_ProgramCounter(void)	
Input parameter	
None.	-
Output parameter	
None.	-
Return value	
bool	Test result When the test completes correctly, “true: success” returns. When it fails, the program step does not return to the source address of the call. If “false” returns, an internal error may exist in the program such as a compilation error and others. (Note1)

* When the terminal I/O output display is used, it takes several seconds to complete the display. The judgment of the test failure should be done by checking the display.

The test result is shown with the LEDs after all the tests finish on the evaluation board which was used to develop this test program.
LED1 (PJ0) lighting: All tests are successful.
LED2 (PJ2) lighting: Register test fails.
LED3 (PJ4) lighting: Program counter test fails.

Note1: This may happen when the inline expansion is done for the called subroutine and others. This test implementation invalidates the inline expansion of the functions.

4. List of Used Drivers

This test library uses the driver and the code in the project of the TPM4KxA_v1.0.0 version.

CMSIS library

Category	Source file name
Start-up	startup_TPM4KxA.s
System (Clock setting and others)	system_TPM4KxA.c

Periph_driver

Category	Source file name
GPIO	txz_gpio.c

In the Project examples

Category	Source file name
BSP (Evaluation board support)	bsp.c
LED output	bsp_led.c

5. Reference Document

For development, refer to the following documents.

- Datasheet of each product
- Reference Manual
- Self-diagnosis Program Application Note - Basic Setting
- ARM® Cortex®-M4 Processor technical Reference Manual
- ARMv7-M Architecture Reference Manual

6. Revision History

Revision	Date	Description
1.0	2019-08-30	First release

RESTRICTIONS ON PRODUCT USE

Toshiba Corporation and its subsidiaries and affiliates are collectively referred to as "TOSHIBA". Hardware, software and systems described in this document are collectively referred to as "Product".

- TOSHIBA reserves the right to make changes to the information in this document and related Product without notice.
- This document and any information herein may not be reproduced without prior written permission from TOSHIBA. Even with TOSHIBA's written permission, reproduction is permissible only if reproduction is without alteration/omission.
- Though TOSHIBA works continually to improve Product's quality and reliability, Product can malfunction or fail. Customers are responsible for complying with safety standards and for providing adequate designs and safeguards for their hardware, software and systems which minimize risk and avoid situations in which a malfunction or failure of Product could cause loss of human life, bodily injury or damage to property, including data loss or corruption. Before customers use the Product, create designs including the Product, or incorporate the Product into their own applications, customers must also refer to and comply with (a) the latest versions of all relevant TOSHIBA information, including without limitation, this document, the specifications, the data sheets and application notes for Product and the precautions and conditions set forth in the "TOSHIBA Semiconductor Reliability Handbook" and (b) the instructions for the application with which the Product will be used with or for. Customers are solely responsible for all aspects of their own product design or applications, including but not limited to (a) determining the appropriateness of the use of this Product in such design or applications; (b) evaluating and determining the applicability of any information contained in this document, or in charts, diagrams, programs, algorithms, sample application circuits, or any other referenced documents; and (c) validating all operating parameters for such designs and applications. **TOSHIBA ASSUMES NO LIABILITY FOR CUSTOMERS' PRODUCT DESIGN OR APPLICATIONS.**
- **PRODUCT IS NEITHER INTENDED NOR WARRANTED FOR USE IN EQUIPMENTS OR SYSTEMS THAT REQUIRE EXTRAORDINARILY HIGH LEVELS OF QUALITY AND/OR RELIABILITY, AND/OR A MALFUNCTION OR FAILURE OF WHICH MAY CAUSE LOSS OF HUMAN LIFE, BODILY INJURY, SERIOUS PROPERTY DAMAGE AND/OR SERIOUS PUBLIC IMPACT ("UNINTENDED USE").** Except for specific applications as expressly stated in this document, Unintended Use includes, without limitation, equipment used in nuclear facilities, equipment used in the aerospace industry, lifesaving and/or life supporting medical equipment, equipment used for automobiles, trains, ships and other transportation, traffic signaling equipment, equipment used to control combustions or explosions, safety devices, elevators and escalators, and devices related to power plant. **IF YOU USE PRODUCT FOR UNINTENDED USE, TOSHIBA ASSUMES NO LIABILITY FOR PRODUCT.** For details, please contact your TOSHIBA sales representative or contact us via our website.
- Do not disassemble, analyze, reverse-engineer, alter, modify, translate or copy Product, whether in whole or in part.
- Product shall not be used for or incorporated into any products or systems whose manufacture, use, or sale is prohibited under any applicable laws or regulations.
- The information contained herein is presented only as guidance for Product use. No responsibility is assumed by TOSHIBA for any infringement of patents or any other intellectual property rights of third parties that may result from the use of Product. No license to any intellectual property right is granted by this document, whether express or implied, by estoppel or otherwise.
- **ABSENT A WRITTEN SIGNED AGREEMENT, EXCEPT AS PROVIDED IN THE RELEVANT TERMS AND CONDITIONS OF SALE FOR PRODUCT, AND TO THE MAXIMUM EXTENT ALLOWABLE BY LAW, TOSHIBA (1) ASSUMES NO LIABILITY WHATSOEVER, INCLUDING WITHOUT LIMITATION, INDIRECT, CONSEQUENTIAL, SPECIAL, OR INCIDENTAL DAMAGES OR LOSS, INCLUDING WITHOUT LIMITATION, LOSS OF PROFITS, LOSS OF OPPORTUNITIES, BUSINESS INTERRUPTION AND LOSS OF DATA, AND (2) DISCLAIMS ANY AND ALL EXPRESS OR IMPLIED WARRANTIES AND CONDITIONS RELATED TO SALE, USE OF PRODUCT, OR INFORMATION, INCLUDING WARRANTIES OR CONDITIONS OF MERCHANTABILITY, FITNESS FOR A PARTICULAR PURPOSE, ACCURACY OF INFORMATION, OR NONINFRINGEMENT.**
- Do not use or otherwise make available Product or related software or technology for any military purposes, including without limitation, for the design, development, use, stockpiling or manufacturing of nuclear, chemical, or biological weapons or missile technology products (mass destruction weapons). Product and related software and technology may be controlled under the applicable export laws and regulations including, without limitation, the Japanese Foreign Exchange and Foreign Trade Law and the U.S. Export Administration Regulations. Export and re-export of Product or related software or technology are strictly prohibited except in compliance with all applicable export laws and regulations.
- Please contact your TOSHIBA sales representative for details as to environmental matters such as the RoHS compatibility of Product. Please use Product in compliance with all applicable laws and regulations that regulate the inclusion or use of controlled substances, including without limitation, the EU RoHS Directive. **TOSHIBA ASSUMES NO LIABILITY FOR DAMAGES OR LOSSES OCCURRING AS A RESULT OF NONCOMPLIANCE WITH APPLICABLE LAWS AND REGULATIONS.**